

# Clear Film

## HOW TO: WET APPLICATION Sihl 3166 ClearSTICK™



- Print (front facing or reverse)
- Allow to dry 24hrs



- Clean surface with non-ammoniated glass cleaner or isopropyl alcohol.



- Spray surface with preferred application fluid (i.e. RapidTac™)



- Spread fluid with nonabsorbent towel until evenly distributed



- Remove liner completely
- Place graphic on desired area (printed side away from surface)



- Squeegee out application fluid
- Work from middle to within 1 " to edge



- Wipe squeegee after each pass (careful not to get application fluid on surface of print)



- Squeegee out final 1" of application fluid one side at a time.



- Final graphic will dry crystal clear

### DID YOU KNOW? Helpful Hints from Sihl ...

A "wet" install refers to a method of applying adhesive products that uses an application fluid, a squeegee and a little patience. The result is a much cleaner and clearer install in the end (but it does require some experience). ClearSTICK features a unique waterbased adhesive that becomes cloudy for the first 24-48 hours after "wet" install, yet dries optically clear. For detailed installation instructions, visit [www.sihlusa.com](http://www.sihlusa.com)